



Sony Scoring Stage

North Entrance
Door = 4'0" x 6'5"
W = 3'9" Usable
H = 6'3" Usable

Cable Storage

Window to Control Room

2'6"
Door to
Control
Room

3'2"
Door to
Sound Lock

Catwalk
Ladder